



# Handling & Removal Instructions

1.43 m<sup>2</sup> Solar Module Packing Crate

ENN Solar Energy co., Ltd

---

## Table of Contents

1.Handling of Packaging . . . . .	1
2.Removal of Packaging . . . . .	2
(1) Preparation . . . . .	2
(2) Removal of Packaging . . . . .	3
3.Disposal of Packaging . . . . .	4

---

## 1. Handling of Packaging

Use forklift or hand hydraulic carrier to handle the packaging.

⚠ Notes:

The packing crate may be cracked by using crane to handle.



Handling with Forklift



Handling with Hand Hydraulic Carrier

---

## 2. Removal of Packaging

### (1) Preparation

Electric Hand Drill, Cross Screwdriver Head

Put the packing crate on ground.



Electric Hand Drill



Screwdriver Head



Notes:

- ① Wear safety glasses to avoid injury of eyes caused by broken nails.
- ② Gloves may be entwined into the electric hand drill and cause injury.
- ③ Nails may prick people.



Packing Crate

---

## (2)Removal of Packaging

Use electric hand drill to remove Roof Board, Side Boards (four) in turn.



 Danger:

Any other tools (e.g.: crowbar) except electric hand drill are forbidden, or else it may easily cause module break or people injury.

---

### 3. Disposal of Packaging

The packing boards must be disposed by qualified units.



Notes:

Broken nail or board may cause injury.

Comments:

1. For module break or people injury caused by operation methods other than this instruction prescribed or suggested, our company does not take direct or indirect legal responsibility.
2. If unable to get expected effect by using operation method mentioned in this instruction, please contact ENN Solar Energy Co., Ltd before taking other measures.
3. The final interpretation right of this instruction belongs to ENN Solar Energy Co., Ltd.